

MUSICA™ Technical Bulletin

MU290 Button Removal

The buttons on the MU290 may need to be modified so that the settings of the amp can not be changed accidentally. This is an easy process to follow. Use a pair of needle nose pliers to grab hold of the gray button and pull straight out.



Both the Power and Bridge/Stereo buttons may be removed.

The
IP-Based
Distributed
Entertainment
Company.

Products Included:

MU290

