



CONNECTING THE REMOTE ANTENNA

CONNECTING THE REMOTE ANTENNA



1. Attach Cable End Connector to the Antenna jack on the mixer.
2. Remove the Cap from the Antenna Base.
3. Connect the External Antenna to the Antenna Base.

1. Attach Cable End Connector to the Antenna jack on the mixer.
2. Remove the Cap from the Antenna Base.
3. Connect the External Antenna to the Antenna Base.

ClearOne.
You're Virtually There™

ClearOne.
You're Virtually There™

TECHNICAL SUPPORT

tel 1-800-283-5936
1-801-974-3760

fax 1-801-977-0087
e-mail tech.support@clearone.com

TECHNICAL SUPPORT

tel 1-800-283-5936
1-801-974-3760

fax 1-801-977-0087
e-mail tech.support@clearone.com