


AP-Ware Compare Utility Property Codes

The AP-Ware Compare Utility is a program that compares two site files and displays the results. This allows the integrator to compare the current programming on an AP unit with a previous configuration file as an aid to troubleshooting a system or for tracking changes to a system for maintenance. Once two sites have been compared in the utility a list of values is presented in the dialog box.



The property codes for each letter code are as follows:

- | | |
|---------------------------|-----------------------|
| L = Labels | D = Adaptive Ambient |
| M = Mute | T = Mic Activation |
| A = AGC | Q = EQ |
| P = Phantom Power | LO = Low Band |
| G = Mic/Line Gain | ME = Medium Band |
| F = Fine Gain | HI = High Band |
| E = Echo Cancellation | H = High Pass Filter |
| R = EC Reference | C = Chairman Override |
| N = Non Linear Processing | |