




1. Connect the Unite 100 Camera USB cable to the computer's USB 3.0 connection.
2. Open Windows Task manager using the control panel.
3. Open 'Imaging devices'. Check if FX3 device appears.
4. If not, open 'Universal Serial Bus Controllers'. There you can find the item 'USB-Serial MFG mode' with yellow icon.




5. Right click on this device. Choose 'Update Driver Software'.



6. Select 'Browse my computer for driver software'.
7. Select 'Let me pick from a list of device drivers on my computer'.



8. Select 'USB Composite Device'.



9. Select 'Next'.

